

DC311XX  
DC313XX

05 Contents 05 Inhalt 05 Contenu 05 Inhoud 05 Sisältö  
 06 Indhold 06 Contenido 06 Contento 06 Conteúdo  
 06 Περιεχόμενα 06 Innehåll




x1



x1



x1



x1



x2



x2


CR2032




x2



x1




06 Getting started 06 Erste Schritte 06 Démarrage 06 Aan de slag 06 Aloitussopas 06 Kom i gang  
 07 Operazioni preliminari 07 Para empezar 07 Para começar 07 Πρώτα βήματα 07 Kom igång




✓




✓



✗




✗




x1





x1





4x AA/LR6





30mm





x1




CR2032




15mm






GB Optional features DE Optionale Funktionen  
 FR Options disponibles IT Opzioni F Valinnaiset ominaisuudet  
 OK Valgírnie funktióner F Funzionalità opzionali  
 ES Opciones disponibles PT Funções opcionais  
 GR Προαιρετικές λειτουργίες πρόσθετων F Måjlīga funkcioner



	Hello	Ding Dong	Westminster	Marimba	Piano	Bell	Telephone	Soft Alert
	•	•					•	•
	•	•	•	•			•	•
	•	•	•	•	•	•	•	•



GB Linking DE Einlernen GR Προγραμματισμός  
 FR Verknüpfung F Linkittäminen OK Forbinde  
 IT Collegamento ES Enlace  
 PT Programação GR Συνδέση F Länkning



GB Trouble shooting DE Fehlerbehebung FR Dépannage NL Probleemoplossing  
 FI Vianmääritys OK Problemløsning IT Risoluzione dei problemi ES Solución de  
 problemas PT Resolução de problemas GR Αντιμετώπιση προβλημάτων F Felsöknning

[livewell.honeywell.com](http://livewell.honeywell.com)

