


Contents **DE** Inhalt **FR** Contenu **M** Inhoud **FI** Sisältö
UK Inhold **IT** Contenuto **ES** Contenido **PT** Conteúdo
GR Περιεχόμενα **SE** Innehåll



x1



x1



x2



x2


CR2032



x2






x1




6mm

Getting started **DE** Erste Schritte **FR** Démarrage **M** Aan de slag **FI** Aloitusopas **UK** Kom i gang
IT Operazioni preliminari **ES** Para empezar **PT** Para começar **GR** Πρώτα βήματα **SE** Kom igång




x1



x1



3x AA/LR6




30mm






x1



x1



CR2032









15mm



GB Optional features 05 Optionale Funktionen 06 Options disponibles 07 Opções disponíveis
 FI Valinnaiset ominaisuudet 08 Valgfrie funksjoner 09 Funzionalità opzionali 10 Opciones disponibles
 PT Funções opcionais 08 Προαιρετικές λειτουργίες 09 Μόβιλις λειτουργίες



	Hello	Ding Dong	Westminster	Marimba	Piano	Bell	Telephone	Soft Alert
	•	•					•	•
	•	•	•	•			•	•
	•	•	•	•	•	•	•	•



		3Hrs 			6Hrs
		9Hrs 			12Hrs



GB Trouble shooting 09 Fehlerbehebung 08 Dépannage 06 Probleemoplossing
 FI Vianmääritys 08 Problemløsning 09 Risoluzione dei problemi 10 Solución de problemas
 PT Resolução de problemas 08 Αντιμετώπιση προβλημάτων 09 Felsöknning

livewell.honeywell.com

