

Installation Instructions

860636329 Revision G / Nov 2019 commscope.com

Discrete Distribution Module Panels (DDM)

General

The CommScope® discrete distribution module (DDM) panels are available in a 24- or 48-port, straight, angled or recessed angled configuration.

The panel consists of a rack mounted base unit, rear cable management hardware, and labels for port numbering. Each panel mounts in a 19-inch (483mm) equipment rack with universal hole spacing.


Ordering information is listed below:


Material ID	Part No.	Description		
760237040	CPP-UDDM-SL-1U-24	CommScope Discrete Distribution Module Panel, SL, UTP, 1U, 24 port		
760237041	CPP-UDDM-SL-2U-48	CommScope Discrete Distribution Module Panel, SL, UTP, 2U, 48 port		
760237042	CPPA-UDDM-SL-1U-24	CommScope Angled Discrete Distribution Module Panel, SL, UTP, 1U, 24 port		
760237043	CPPA-UDDM-SL-2U-48	CommScope Angled Discrete Distribution Module Panel, SL, UTP, 2U, 48 port		
760237044	CPPR-UDDM-SL-1U-24	CommScope Recessed Angled Discrete Distribution Module Panel, SL, UTP, 1U, 24 port		
760237045	CPPR-UDDM-SL-2U-48	CommScope Recessed Angled Discrete Distribution Module Panel, SL, UTP, 2U, 48 port		
760237046	CPP-SDDM-SL-1U-24	CommScope Discrete Distribution Module Panel, SL, STP, 1U, 24 port		
760237047	CPP-SDDM-SL-2U-48	CommScope Discrete Distribution Module Panel, SL, STP, 2U, 48 port		
760237048	CPPA-SDDM-SL-1U-24	CommScope Angled Discrete Distribution Module Panel, SL, STP, 1U, 24 port		
760237049	CPPA-SDDM-SL-2U-48	CommScope Angled Discrete Distribution Module Panel, SL, STP, 2U, 48 port		
760237050	CPPR-SDDM-SL-1U-24	CommScope Recessed Angled Discrete Distribution Module Panel, SL, STP, 1U, 24 port		
760237051	CPPR-SDDM-SL-2U-48	CommScope Recessed Angled Discrete Distribution Module Panel, SL, STP, 2U, 48 port		
760207274	CPP-UDDM-M-1U-24	CommScope Discrete Distribution Module Panel, M-series, UTP, 1U, 24 port		
760207282	CPP-UDDM-M-2U-48	CommScope Discrete Distribution Module Panel, M-series, UTP, 2U, 48 port		
760207290	CPPA-UDDM-M-1U-24	CommScope Angled Discrete Distribution Module Panel, M-series, UTP, 1U, 24 port		
760207308	CPPA-UDDM-M-2U-48	CommScope Angled Discrete Distribution Module Panel, M-series, UTP, 2U, 48 port		
760237052	CPP-UDDM-KJ-1U-24	CommScope Discrete Distribution Module Panel, KJ, UTP, 1U, 24 port		
760237054	UNP-UDDM-SL-1U-48	Uniprise Discrete Distribution Module Panel, Cat6, UTP, 1U, 48 port		
760237055	UNPA-UDDM-SL-1U-48	Uniprise Angled Discrete Distribution Module Panel, Cat6, UTP, 1U, 48 port		
760237060	NPP-UDDM-SL-1U-48	NETCONNECT Discrete Distribution Module Panel, Cat6, UTP, 1U, 48 port		
760237061	NPPA-UDDM-SL-1U-48	NETCONNECT Angled Discrete Distribution Module Panel, Cat6, UTP, 1U, 48 port		
760237066	CPP-6A-SDDM-SL-1U-48	Commscope Discrete Distribution Module Panel, Cat 6A, STP, 1U, 48 port		
760237067	CPP-6-SDDM-SL-1U-48	Commscope Discrete Distribution Module Panel, Cat 6, STP, 1U, 48 port		
760241547	CPP-UDDM-KJ-2U-48	Commscope Discrete Distribution Module Panel, KJ, UTP, 2U, 48 port		



760245529	CPPA-UDDM-M-1U-24-WH	CommScope Angled Discrete Distribution Module Panel, M-series, UTP, 1U, 24 port, White
760245530	CPPA-UDDM-M-2U-48-WH	CommScope Angled Discrete Distribution Module Panel, M-series, UTP, 2U, 48 port, White
760245531	CPP-UDDM-M-1U-24-WH	CommScope Discrete Distribution Module Panel, M-series, UTP, 1U, 24 port, White
760245532	CPP-UDDM-M-2U-48-WH	CommScope Discrete Distribution Module Panel, M-series, UTP, 2U, 48 port, White
760245361	CPPA-6A-SDDM-SL-1U-48	CommScope Discrete Angled Distribution Module Panel, Cat 6A, STP, 1U, 48 port


Note: sample product images shown below.





DDM Flat UTP Panel | CPP-UDDM-SL-1U-24

DDM Angled Panel | CPPA-UDDM-SL-1U-24



DDM Recessed Angled Panel CPPR-UDDM-SL-2U-48

How to Contact Us

- To find out moreabout CommScope® products, visit us on the web at www.commscope.com/
- For technical assistance:
 - Within the United States, contact your local account representative or technical support at 1-800-344-0223. Outside the United States, contact your local account representative or **PartnerPRO**™ Network Partner.
 - Within the United States, report any missing/damaged parts or any other issues to CommScope Customer Claims at 1-866-539-2795 or email to claims@commscope.com. Outside the United States, contact your local account representative or PartnerPRO Network Partner.

Tools Required

- Phillips head screwdriver
- Flat blade screwdriver, max 2.9mm dia.

Parts List

Verify parts against parts list below:

		Qua	intity			
24-Port Flat Panel	48-Port Flat Panel	24-Port Ang Panel	48-Port Ang Panel	24-Port R-Ang Panel	48-Port R-Ang Panel	Description
1	_	_	_	_	_	24-port flat panel
_	1	_	_	_	_	48-port flat panel
_	_	1	_	_	_	24-port angled panel
_	_	_	1	_	_	48-port angled panel
_	_	_	_	1	_	24-port recessed angled panel
_	_	_	_	_	1	48-port recessed angled panel
4	4	4	4	4	4	P12-24 x ½" mounting screws *
1	2	1	2	1	2	Adhesive label (5 per strip)
1	2	1	2	1	2	Cable management bar
4	8	4	8	4	8	Hook-and-loop straps
2	4	2	4	2	4	Hex nut with lock washer **
1	1	1	1	1	1	Instruction sheet
4	8	4	8	-	-	Trough, Cable Mgmt ***




MARNING – Important Safety Instructions

When using this product, the following basic safety precautions should be followed to reduce the risk of fire, electric shock, and injury to persons:

- 1. Never install communications wiring in wet locations unless it is designed for wet locations.
- 2. Never install this product during a lightning storm. There is a remote risk of electric shock.
- 3. Never touch uninsulated communication wiring or terminals unless the communication circuit has been disconnected at the network interface.
- 4. Caution: All wiring that connects to this equipment must meet applicable local and national building codes and network wiring standards for communication cable.
- Netconnect Panels do not include 12-24 mounting screws.
- ** Hex nut and washer only included in shielded panels.

A. Installation of Panel


Step 1 – Mount Panel to Rack




1. Mount panel to rack.

Step 2 – Assemble and Install Rear Cable Manager


1. Attach cable bar as shown and insert four hook-and-loop straps to cable bar.



Step 3 - Populate Panel with Jacks and Connect Ground *




48-Port Panel



- 1. Connect cables to jacks per instructions provided with the individual jacks.
- 2. Populate panel with jacks and route cabling as shown.

Note: Secure cables using the hook-and-loop straps provided.

- 3. * For shielded panels only, use one of two grounding lug connections provided on rear of panel and hex nut with lock washer to ground the panel per approved local practices.
 - ** For HD Angled Panel 760245361, use both ground lug connections provided on the rear of the panel and hex nut with lock washer to ground the panel per approved local practices.



Step 4 – Attaching Information Labels





Figure 1 Figure 2

- 1. Enter information on the white information labels provided. Note that mounting surfaces should be cleaned prior to attaching labels. Remove protective backing from labels and attach as shown in figure 1.
- 2. Print port designations on label sheets provided. Insert labels and label retainers as shown in figure 2.
- 3. To print a designation label, go to http://www.commscope.com/Resources/Labeling-Templates and scroll down to *Panels* and select the proper label template.

Note: Labeling website has two options for printing labels; letter size and A4 size.

www.commscope.com 860636329
Instruction sheet


B. To Remove a Jack from Panel



12 Port Jack Removal

6 Port Jack Removal

- 1. Insert a small, 2.9mm dia. max flat-blade screwdriver into the slot above the jack and rotate to release the latch.
- 2. Remove jack from rear of panel.
- 3. Note cable management bar may need to be removed to enable access to the release slot on some jack positions.



M-Series Jack Removal

Trade-marks

All trademarks identified by ® or ™ are registered trademarks or trademarks, respectively, of CommScope, Inc. This document is for planning purposes only and is not intended to modify or supplement any specifications or warranties relating to CommScope products or services. CommScope is committed to the highest standards of business integrity and environmental sustainability, with a number of CommScope's facilities across the globe certified in accordance with international standards, including ISO 9001, TL 9000, and ISO 14001.

Further information regarding CommScope's commitment can be found at www.commscope.com/About-Us/Corporate-Responsibility-and-Sustainability.

Contact information

Visit our website or contact your local CommScope representative for more information.

For technical assistance, customer service, or to report any missing/damaged parts, visit us at: http://www.commscope.com/SupportCenter

Or Contact PartnerPRO Network Partner https://www.commscope.com/Partners/PartnerPRO-Network

This product may be covered by one or more U.S. patents or their foreign equivalents. For patents, see www.cs-pat.com